

## 35768 - Integrated 4ft LED Glass Tubes

### LED18ET8/G/4/835

- Convert your existing linear fluorescent fixture to LED lighting without needing a comprehensive reinstall.
- Each LED tube is outfitted with an internal GE driver.
- The GE integrated LED tubes run on electronic T8 instant-start or programmed start ballasts.
- 66% longer life than LFL (50,000 vs. 30,000 hours)
- 🖙 No UV
- Easy disposal, non-hazardous waste
- Check ballast compatibility at www.gelighting.com/LEDTUBESballast-compatibility
- IL Listed
- DLC Listed

# **Product Photo**



## **GENERAL CHARACTERISTICS**

Product Technology
Rated Life (Hours)
LED Tube Type
Environmental Rating
10 Digit U
Lamp Count
Life in Years
Requested Structure
Estimated Energy Cost per Year
Bulb Shape

### PHOTOMETRIC CHARACTERISTICS

T8 STICS 18

18 W 2200 lm 3500 K

48.0 in

LED

50000 h

LED\_Tube\_Glass 4316835768

Glass

45.7 yr Sleeve

2.17

1

### PRODUCT INFORMATION

Rated Beam Spread

Color Temperature

Initial Lumens-nominal

Product Code	35768
Description	LED18ET8/G/4/835
Alternative Unit Of Measure	EACH
Standard Package Quantity	20
Ean UPC	043168357685
Standard Package GTIN	00043168357685
No Of Items Per Sales Unit	1
No Of Items Per Standard Package	20
Sales Unit	Each
UCC	043168357685
Alternative Unit Of Measure	CASE
Standard Package Quantity	20
Ean UPC	043168357685
Standard Package GTIN	10043168357682
No Of Items Per Sales Unit	
No Of Items Per Standard Package	20
Sales Unit	Case
UCC	043168357685

# DIMENSIONS

Bulb Max Overall Length-MOL

## **ELECTRICAL CHARACTERISTICS**

Drive Current	45.7
Energy Efficiency Class	yr
Voltage <nom></nom>	120 V
Rated power (Watts)	18 W

#### **CAUTIONS & WARNINGS**

## Caution

#### Risk of fire

Use only in place of fluorescent lamps specified on label

If the lamp or luminaire exhibits undesirable operation, immediately turn off power, remove lamp from luminaire and contact manufacturer

Direct replacement for 25W/48T8, 28W/48T8, 30W/48T8, 32W/48T8 lamps only

Do not install this lamp in a pre-heat luminaire

This lamp only operates on electronic ballasts

If lamp does not light when luminaire is energized, remove lamp from luminaire and contact lamp manufacturer or qualified electrician